

CONGRATULATIONS ON THE PURCHASE OF A CARANGA®.

FIRST TIME USE

When using the Caranga® for the first time, we strongly recommend to have it burn for 30 minutes without cooking meals. This initial period is necessary.

USEFUL HINTS AND PRECAUTIONARY MEASURES

- 1) The barbecue can be used only out of doors.
- 2) Always install the barbecue on a solid base, away from inflammable and meltable objects.
- 3) It is recommended to empty out the barbecue each time it has been used.
- 4) The bowl has a capacity of approximately 16 L,
Do not use too much charcoal in the bowl (max. 50 %).
- 5) Caution! Do not use spirit or petrol for lighting or re-lighting! Use only fire-lighters complying to EN 1860-3!
- 6) Never move the barbecue before the fire is completely extinguished and the barbecue is cooled off completely.
- 7) Keep children and pets at a safe distance, protect yourselves against the fire.
- 8) For safety reasons, we advise to keep a bucket of water or sand in the neighbourhood of the burning barbecue.
- 9) Never roast meat in the flames. Wait to put the cooking grill in place until the charcoal is covered with a fine layer of ashes.
For fatty food, we recommend to use a grill pan.
- 10) Always use dry and purified charcoal of the DIN 51749 type.

GUARANTEE

The Caranga® comes with a limited two years warranty on production flaws, from the date of purchase and to the extent the use corresponds with the present instructions for use. The receipt mentioning the date of purchase counts as guarantee card.

This Caranga® is not suited for professional use.

Wear, corrosion, deformation and discoloration of the parts that are directly exposed to the fire is quite normal and will therefore in no event ever be considered as a production flaw : it is the logical result of their use. Hence, the ground grid can be strongly deformed after some time and it is normal to have this part replaced.

STORAGE

All chromed parts such as grids and handle should be stored inside in a dry area after every use.

