


### **Assembly Instructions**

Please check all packing material carefully before discarding, as some parts may be encased in the packing material

**Step 1.** Attach Legs (E) to Bottom Ring-Small (D2) by using Bolts (I) and Nuts (J), hand tightened, do not fully tightened first, follow the same step for the Upper Ring-Large (D1). Fully tightened all bolts with provided Allen Wrench(G). (View Fig 1)



**Step 2.** Screw Screen Handle (H) to the Fire Screen (A). (View Fig 2)



**Step 3.** Place the Fire Bowl (C) on the assembled base and put the Grate (B) in the fire bowl. Attach the assembled fire screen on the Fire Bowl.



Your fire pit is ready for use now.

## WARNING FOR 30" STEEL FIRE PIT

- \* FOR OUTDOOR USE ONLY.
- \* KEEP THE OUTDOOR FIRE PIT AT LEAST 20 FEET AWAY FROM ANY FLAMMABLE SURFACE OR DWELLING.
- \* KEEP AWAY FROM CHILDREN AND PETS.
- \* CHECK WITH THE LOCAL OFFICIALS AND FIRE DEPARTMENT FOR ORDINANCES REGARDING THE USE OF OUTDOOR FIRE PITS.
- \* NEVER USE GASOLINE, KEROSENE, LIGHTER FLUID, ALCOHOL OR ANY OTHER FLAMMABLE MATERIAL TO LIGHT YOUR FIRE.
- \* ALWAYS USE GLOVES AND PROTECTIVE GLASSES WHEN LOADING THE FIRE PIT OR EXTINGUISHING THE FIRE.
- \* NEVER LEAVE THE FIRE PIT UNATTENDED WHEN NOT IN USE
- \* DO NOT MOVE THE FIRE PIT WHEN HOT OR LIT
- \* ALWAYS SET THE OUTDOOR FIRE PIT ON A LEVEL NON-FLAMMABLE SURFACE.
- \* NEVER OVER LOAD THE OUTDOOR FIRE PIT
- \* ALWAYS MAKE SURE THE FIRE AND ASHES ARE COMPLETELY EXTINGUISHED WHEN NOT IN USE OR UNATTENDED
- \* HAVE A FIRE EXTINGUISHER AVAILABLE NEAR THE FIRE PIT IN CASE OF EMERGENCY
- \* THE LOG GRATE IS NOT INTENDED FOR COOKING, AND SHOULD NOT BE USED FOR THIS PURPOSE
- \* DO NOT BURN COAL, LEAVES OR OTHER COMBUSTIBLE MATERIALS IN THE FIRE PIT

### Care and Maintenance












This fire pit is a quality built product; the frame structure is made of powder coated steel, and under normal use and conditions is rust resistant. However, if scratched, or under certain atmospheric conditions rust may occur. Should rust occur, we suggest using a steel brush or steel wool to remove the rust on the affected area. When the area is clean, apply a coat of primer and when dry spray a high heat anti rust metal paint onto the frame.

We also recommend that after each use, the firepit be cleaned, and when not in use the firepit be covered.

## Assembly Instructions: ITEM#SP-FT007 30" STEEL FIRE PIT

Please check all packing material carefully before discarding, as some parts may be encased in the packing material.

### Part List

Part List	Description	Qty.	Drawings
A	Fire Screen	1	
B	Grate	1	
C	Fire Bowl	1	
D1	Upper Ring-Large	1	
D2	Bottom Ring-Small	1	
E	Leg	4	
F	Poker	1	
G	Allen Wrench	1	
H	Screen Handle	1	
I	Bolt	16	
J	Nut	16	



**Distribuidor oficial para España:**

**The Barbecue Store  
Avda. Carmen Saenz de Tejada, 1  
29650 Mijas Costa (Málaga)  
Teléfono: 952477152 - 952477161  
Fax.: 952580781  
Email: [dmbrico2@telefonica.net](mailto:dmbrico2@telefonica.net)  
<http://www.thebarbecuestore.es>**