


INSTALLATION INSTRUCTIONS

DIMENSIONS





Side view - lid down



Vent 250mm x 25mm (required when installed separately to barbecue)

• This appliance requires venting. This vent is to allow air into the enclosure for the correct combustion of gases and for the correct exhausting of the products of combustion. The vent must be no less than 250mm x 25mm unless installed adjacent to integrated barbecue refer to diagram on page 13. For more information on all Beefeater products, or for dimension and installation information, call into your retailer, phone or email our customer care team or visit our website:



Distribuidor oficial para España:

The Barbecue Store Avda. Carmen Saenz de Tejada, 1 29650 Mijas Costa (Málaga) Teléfono: 952477152 - 952477161 Fax.: 952580781 Email: dmbrico2@telefonica.net http://www.thebarbecuestore.es